

# Pandora BAND

## QUICK GUIDE

Our web-site: [pandorainfo.com](http://pandorainfo.com)  
Customer support: [support@pandorainfo.com](mailto:support@pandorainfo.com)



v 1.0

### SET

1. Quick guide	1 pc.
2. Capsule	1 pc.
3. Band (black)	1 pc.
4. Charging cable (USB - micro USB)	1 pc.
5. Packaging	1 pc.

**!** THE MANUFACTURER RESERVES THE RIGHT TO CHANGE THE SET AND CONSTRUCTION OF THE PRODUCT TO IMPROVE ITS TECHNOLOGICAL AND OPERATIONAL PARAMETERS WITHOUT A NOTIFICATION.

### GENERAL INFORMATION

Wrist-wearable band designed to conveniently control vehicle equipped with Pandora Bluetooth system (BT5.0, BT5.2).

**!** PANDORA BAND IS A UNIFIED CONTROL DEVICE - ITS OPERATION DEPENDS OF THE SECURITY SYSTEM FUNCTIONAL. IT IS NECESSARY TO ENABLE «USE D-030 AS A RADIO TAG» OPTION TO USE BAND AS AN OWNER'S AUTHORIZATION DEVICE.

**DISPLAY:** OLED, 128x32  
**INTERFACE:** Bluetooth 5.0  
**SENSORS:** accelerometer  
**ACCU:** Li-Po, 85 mAh  
**CHARGING INPUT:** microUSB

**ADDITIONALLY:  
CONTROL BUTTON**


**OPERATING RANGE:**  
from -10°C to +40°C

### COMPATIBILITY

Pandora: Pandora Elite / Pandora Smart Pro V3 / Pandora Camper Pro V2 / Pandora Camper Mini



### SWITCH ON/OFF THE BAND









Press and hold the  button for 3 sec to switch ON, 8 sec to switch OFF.

### CHARGING THE BAND







There is a battery charge indicator on the display. Charge the battery if the device does not turn on or the charge indicator shows low level (10%).

- remove capsule from the band;
- connect the micro-USB connector of the cable to the capsule;
- connect the USB connector of the cable to the charger (not included in the set);
- charge the battery until the indicator is full (100%);
- disconnect the cable and insert the capsule into the band - device is ready for use.

### BUTTON'S FUNCTIONS













PRESS	FUNCTION
 <b>briefly</b> (ignition off)	Arming/disarming the security system
 <b>1 sec</b> (engine running)	Switch on «Hold On» mode
 <b>2 sec</b> (system disarmed)	Change the «Main owner's phone number»
 <b>3 sec</b> (ignition on)	Activate/deactivate Service mode
 <b>3 sec</b> (band is switched off)	Switch on the BAND
 <b>6 sec</b> (programming)	Pair the BAND with a base unit
 <b>8 sec</b> (band is switched on)	Switch off the BAND
 <b>10 sec</b>	Firmware update

## INFORMATION ICONS

 Security system status	 Connection state
 Current time*	 Charge indicator
 Process scale	 Counter*


\* PANDORA BAND AUTOMATICALLY SYNCHRONIZES THE TIME WITH THE SYSTEM BASE UNIT AND DISPLAYS COUNTED STEPS (THE COUNTER IS RESET BY TIME - 0:00 AM).

## SECURITY ZONE ICONS


 Motion sensor	 Tilt sensor
 Shock sensor (warning level)	 Add. sensor (warning level)
 Shock sensor (alarm level)	 Add. sensor (alarm level)
 Ignition	 Brake pedal
 Front hood	 Trunk
 Doors	 Low voltage

## FIRMWARE UPDATE

Install «Pandora BT» (Android/iOS) or «Pandora Specialist» Apps on a smartphone or a tablet, equipped with Bluetooth 4.0 or higher.

- open mobile App, search for a device;
- press and hold control button  for 10 sec or connect micro USB cable while holding control button;
- choose the BAND in the mobile App and start the update: «INTERNET» – software will be downloaded from a server; «FILE MANAGER» – select previously downloaded software (Android only).

## PAIRING THE BAND

- Enter the programming level №1 «Pairing remote controls» in accordance with a security system manual;
- Press and hold control button  for 6 sec;
- The security system will confirm pairing with a beep. Finish pairing in accordance with the security system manual.

## ACCEPTANCE CERTIFICATE

Serial number \_\_\_\_\_ Date of production \_\_\_\_\_

Responsible person's signature (stamp) \_\_\_\_\_

Packager \_\_\_\_\_  
Signature (Personal stamp)

## WARRANTY CARD

Model **Pandora Band**

Serial number \_\_\_\_\_

Date of purchase « \_\_\_\_\_ » \_\_\_\_\_ 20 \_\_\_\_\_ y

\_\_\_\_\_  
Seller's (installer's) stamp

Seller's signature \_\_\_\_\_